

Germinex - Disinfectant cleaner

Triple action (bactericidal, fungicidal and virucidal) general disinfectant cleaner. Authorised for environmental and food industry use. Contact sanitiser: surfaces and equipment. Application by professional personnel. Complies with standard UNE-EN 13697 in dirty conditions for specific uses with the test organisms *Listeria monocytogenes* and *Salmonella typhimurium*.

Complies with standard UNE-EN 14476 in dirty conditions at a concentration of 5.20%, contact time of 5 minutes against Adenovirus type 5 and Murine Norovirus, as well as against Norovirus, Rotavirus and Adenovirus, and enveloped viruses including Human coronavirus 229E.

Instructions for use and dosage

Contact sanitiser: surfaces and equipment, using pump spray or trigger spray or washing with cloth or mop with product neat or diluted in water at 5% to 30%. Allow the product to act for 5 to 15 minutes and rinse with water. Application of the product in the food industry for contact disinfection: use on surfaces and equipment in the absence of food.

Technical data

Appearance	Liquid
Color	Yellow
Density (g/ml)	1.04 ± 0.02
pH (5%)	11.5 ± 0.5
Odor	Citrus
Solubility in water	Soluble
Biodegradable	

Composition

Alkylbenzyltrimethylammonium chloride 6.5%

Excipients and solvents c.s.p.100%

Precautions and handling

Do not inhale the spray/fumes/aerosol. Wear protective gloves/clothing/goggles/mask. Wash any contaminated clothes before using them again. Avoid release into the environment. Clean up spills. Dispose of content and/or its container as hazardous waste through an authorised waste collector, in accordance with current regulations.

This product complies with current legislation on biodegradability and Regulation (EU) No 528/2012 on biocidal products.

Germinex is manufactured under rigorous quality control, following Spanish and EU toxicology and environmental standards.



UFI: PJM8-NDRP-QXEU-OXDR

Contact

Frontmatec Hygiene GmbH
Phone: +49 252 185 070
E-mail: hygiene@frontmatec.com
itec-hygiene.com
frontmatec.com